



Address of Work:  
Civic Centre, High Street,  
Uxbridge, UB8 1UW

Measure:  
Cavity Wall Insulation.

### Scope Process of Work:

- Insulation process will be treated on an elevation-by-elevation basis given the nature and scale of the building.
- Unique drilling pattern will be performed to conform with manufacturers regulations to ensure all areas are insulated adequately. This is done in the mortar of the walls and not through bricks.
- Higher locations will be carried out with use of Cherry-picker.
- All areas checked and scoped and insulated following drilling pattern being drilled.
- As each area is insulated it is followed up by the holes being filled in. We refill the holes with sand and cement by also adding crushed stones in the mix as the current external mortar show broken/crushed stone prior to works. We do this so that the external appearance is uniformed. Within a few months and with weathering they will not be noticeable as they would have been blended.

This process is carried out on all external elevations being insulated with cavity wall insulation.

Andreas Frangeskides  
Director

Ecologic Energy.

