



Bird boxes should be positioned near vegetation and 2-3m above the ground. Bird boxes should face between north and east.

The bat boxes should be at least 4m above ground (or as high as possible) and away from artificial light sources. Bat boxes should face between south-east and south-west.



8



**Key:**

- ◆ 2F Schwegler Bat Box or Large Multi-Chamber Woodstone Bat Box
- Vivara Pro Seville 32mm/ 28mm Woodstone Nest Box

**Title:** Bird and Bat Box Locations  
**Site:** Uxbridge  
**Client:** Montagu Evans

the  
**ecology**  
 partnership

The Ecology Partnership  
 Thorncroft Manor  
 Thorncroft Drive  
 Leatherhead  
 KT22 8JB  
 t: 01372 364133  
 e: [info@ecologypartnership.com](mailto:info@ecologypartnership.com)  
 w: [www.ecologypartnership.com](http://www.ecologypartnership.com)